


MVS Series Antennas Operating Instructions

Dec 2005

Version 3.3


TracStar Systems, Inc.
1984 West New Hampshire Street
Orlando, FL 32804
Ph: 407-650-9054
Fax: 407-650-9086
www.tracstar.net



TracStar
SYSTEMS



TracStar Controller Menu Grid





Contents

1. Theory of Operation
2. Antenna Setup Options
3. Antenna Operations and Display Unit Instructions



This manual and its contents are considered proprietary intellectual property of TracStar Systems, Inc. Unauthorized use or distribution is specifically prohibited. Contents are subject to change without notice. Contents are protected by law.

Copyright 2004, TracStar Systems, Inc.



Using the Manual



ARROW 1X
MAIN 2X

PgUP / PgDn

- Click on HOME / HOUSE symbol to return to INDEX page
- Means it is something *TracStar* feels is important to you.
- Number of times operator must touch respective keypad position to accomplish the direction(s) being given.
- PgUP / PgDn navigates the MVS Manual by decreasing or increasing the page number respectively.



Summary Slide

| | |
|---|----|
| Theory of Operation | 7 |
| System/Cabling Block Diagram | 9 |
| IFL CABLE CONNECTIONS | 10 |
| Antenna Setup Options | 11 |
| 1. Quick Setup Reference – Known Reference Satellites | 12 |
| 2. Quick Setup Reference – From a Script | 13 |
| 3. Quick Setup Reference – Using Sky Scan | 14 |
| Technical Manual DATA Presentation | 15 |
| 1.0 READY | 17 |
| 1.1 Set Reference Satellite | 19 |
| 1.2 Select Data Satellite | 22 |
| 1.3 Polarity | 24 |
| 1.4 Manual GPS Input | 26 |
| 1.5 Manual Compass Input | 28 |
| 2.0 USER SETUP | 30 |
| 2.1 Jog 31 | 31 |
| 2.2 Satellite Parameters | 33 |
| 2.3 Reference Satellite | 35 |
| 2.4 Peak/Re-reference/Lock Methods | 38 |
| 3.0 TECH SETUP | 41 |
| 3.1 Set Option | 43 |
| 3.2 Set Test | 44 |
| 3.3 Level/Motor Control Page | 46 |
| 3.4 Select Modem/Antenna/Pol | 48 |
| 3.5 Move/RF_SAFE | 50 |
| 3.6 Azimuth Stow/External Switch | 52 |



Summary Slide (cont.)

| | |
|---|-----|
| 3.7 USAdvb | 54 |
| 3.8 LNB GAIN | 56 |
| 4.0 DIAGNOSTICS | 58 |
| 4.A Axis Angles | 59 |
| 4.B B Page | 60 |
| 4.C C Page | 61 |
| 4.D Scan Hits | 62 |
| 4.E Tilt Angles | 63 |
| 4.F Axis Position Transducer Readout | 64 |
| 4.G GPS Data | 65 |
| 4.H Axis Zero Offsets | 66 |
| 4.I Axis Offsets | 68 |
| 4.J Azimuth Scan Width | 70 |
| 4.K SFE SFR | 72 |
| 4.L Axis Diagnostics (Progresses to 4.T) | 74 |
| TRUBLESHOOTING | 83 |
| PEDESTAL | |
| Pedestal | 84 |
| DATA SHEETS | |
| MVS750 | 96 |
| MVS960 & 960P | 98 |
| MVS1200 | 100 |
| Appendix B – Connection Directions | |
| Gilat 360E | 103 |
| EMS Technologies | 104 |
| iDirect | 106 |
| Linkstar | 107 |
| Vipersat | 108 |



Theory of Operation

Antenna Description

- Three axis, polarization over elevation over azimuth
- Configurable for operation on most satellites
- Designed for operator simplicity, performs precise antenna to satellite alignment with the push of a button or a switch
- Pedestal Description:
 - High precision motors with optical encoders
 - Very low backlash drive system
- Each antenna is fully integrated with
 - GPS
 - Compass
 - DVB Receiver
 - Base level sensor
 - Antenna Control System with User Interface

- Satellite Acquisition Description
- Upon power up and deployment, the following acquisition sequence takes place:
 - Compass aligns the antenna with south (if in the northern hemisphere, to the north if in the southern hemisphere)
 - Antenna acquires GPS for high precision geographic location information
 - Antenna precisely sets elevation angle and sweeps through a selected reference satellite, monitoring signal characteristics of the reference satellite
 - Antenna peaks on reference satellite until the center of the antenna beam is located as a calibration
 - Antenna then peaks on the satellite of interest and performs a high precision alignment to the satellite
 - Antenna sends GPS to satellite modem (if applicable)
 - Satellite modem initiates contact with network operations



Antenna Description

- DirectPoint™ technology closely couples with the satellite modem thus enhancing the satellite acquisition accuracy and reducing the startup time. The antenna goes directly to the data satellite and using enhanced communications capability with intelligent modems is able to acquire, lock and peak on the specific satellite without the traditional pre-alignment (reference satellite) stage.




The DirectPoint mode is invoked by setting "10000" as the Lock Method Word in the User Setup Page 2.4 and "iDirect" as the Modem in Tech Setup Page 3.4.

Satellite Acquisition Description

- Upon power up and deployment, the following acquisition sequence takes place:
 - Compass aligns the antenna with south (if in the northern hemisphere, to the north if in the southern hemisphere)
 - Antenna acquires GPS data for high precision geographic location information
 - Using DirectPoint™ and bypassing the selected reference satellite, the antenna pointing algorithm precisely scans to the selected data satellite
 - Monitoring signal characteristics specific to this data satellite, the antenna peaks on the center of the satellite beam and performs a high precision alignment to this satellite
 - After completion of the peaking sequence data is sent to the modem to enable transmit
 - The modem can then automatically initiate contact with the network operations center and be commissioned into the network




System/Cabling Block Diagram





IFL CABLE CONNECTIONS

There are two different types of coaxial connectors on the IFL cables. The cable connecting to the antenna is shown below. The two-piece connection allows for the O-ring seal in the smaller nut to be placed on the F Type connector first. Once the cable is connected, the smaller nut is tightened against the cable end allowing the O-ring to provide a moisture proof seal.





Antenna Setup Options

1. **Quick Setup**
 1. This setup is performed for an antenna system to be used in a geographical region for the first time.
 2. The user has known Reference Satellite information.
 3. The user does not have Reference Satellite frequencies.

2. **Quick Setup Reference from Script**
 1. This setup is performed for an antenna system to be used in a geographical region for the first time.
 2. The user has a script, i.e., orbital positions and frequencies exist for the Reference Satellites and therefore can be entered into the antenna controller.

3. **Quick Setup Reference Using SkyScan**
 1. This setup is performed for an antenna system to be used in a geographical region for the first time.
 2. There is no information for Reference Satellites.

4. **After the Reference Satellites are input, the following criteria should be considered in selecting them.**
 1. There can be up to 12 Reference Satellites in the library. A general rule is to select 3-4.
 2. The antenna "rated" the satellites during the ScanSky. Reference satellite positions ending with the letter "A" are the most desirable, then "B", then "C". "Z" indicates that carrier power was not found.
 3. Try to select satellites that are off to the side (east or west) of the users longitude position, i.e., lower on the horizon is better.




NOTE:

Locate the antenna so that it has a view of the orbital arc.

Orient the antenna so that it comes up generally to the south (if located north of equator), north (if located south of equator).

1. Quick Setup Reference – Known Reference Satellites

| Step | Function | Action | Display Page |
|------|--|---|---|
| 1. | Power up antenna | Turn on power at ACU | READY |
| 2. | Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP,[Code 0] Tech Setup [CODE 13] READY |
| 3. | Clear existing satellite data. (Page 3.2) | From READY page Main 2x Arrow 2x + or – to Enter + Enter | READY TECH SETUP [Code 13] SET TEST, [NONE] [CLEAR REF DATA] [CANCEL] [RUN NOW] READY |
| 4. | Input reference satellite parameters. (Page 2.3) Go to reference satellites entry page Leave both default frequencies 10799 Set scan type to Freq Repeat, up to 12 Ref satellites | From READY page Main 1x Arrow 3x Enter + or – to Ref Sat Long ENTER - to [10799] ENTER + TO [Freq] ENTER | READY USER SETUP [Rs 1] [XXX.X] [XXX.X] [XXX.X] [10799] [SS] [Freq] |
| 5. | Run Frequency Scan (Page 3.2 – Set Test/Freq Scan) | From READY page Main 2x Arrow 2x + or – to ENTER + Enter | READY TECH SETUP, [Code 13] SET TEST, [NONE] [SCAN FREQ] [cancel] [RUN NOW] READY |
| 6. | (Input Reference Satellites Page 1.1) Select RefX Satellite Select RefY Satellite | From Ready page: Arrow 1x + or – through Ref Sat List ENTER + or – through Ref Sat List Enter Main | READY SetREF, X XXX.X SetREF, Y XXX.X READY |
| 7. | (Input data satellite parameters Page 1.2) Toggle between SatA and SatB Input orbital position for SatA Input orbital position for SatB | From READY page: Arrow 2x + or – + or – Enter | READY SELECT DATA [SatA] or [SatB] XXX.X |




NOTE:

Locate the antenna so that it has a view of the orbital arc.

Orient the antenna so that it comes up generally to the south (if located north of equator), north (if located south of equator).

2. Setup Quick Reference: From A Script

| Step | Function | Action | Display Page |
|------|---|---|---|
| 1. | Power up antenna | Turn on power at ACU | READY |
| 2. | Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, ENTER Main 2x | READY TECH SETUP [Code 0] Tech Setup [CODE 13] READY |
| 3. | Clear existing satellite data. (Page 3.2) | From READY page Main 2x Arrow 2x + or – to ENTER + ENTER | READY TECH SETUP [Code 13] SET TEST, [NONE] [CLEAR REF DATA] [cancel] [RUN NOW] READY |
| 4. | Input reference satellite parameters (Page 2.3) Select Reference Satellite 1 Input orbital position for Ref 1 Input primary frequency for Ref1 Input secondary freq. for Ref1 Repeat, up to 12 Ref satellites | From READY page Main 1x Arrow 3x ENTER + or – then ENTER + or – then ENTER + or – then ENTER + or – then ENTER | READY USER SETUP [Rs 1] [XXX.X] [XXXXX] [XXXXX] [Rs2] |
| 5. | (Input reference satellites Page 1.1) Select RefX satellite Select RefY satellite | From READY page: Arrow 1x + or – then ENTER + or – then ENTER | READY Set Ref XXX.X XXX..X |
| 7. | Input data satellite parameters. (Page 1.2) Toggle between SatA and SatB Input orbital position for SatA Input orbital position for SatB | From READY page Arrow 2x + or – then Enter + or – then Enter + or – then Enter | READY SELECT DATA [SatA] or [SatB] XXX.X XXX.X |



NOTE:

Locate the antenna so that it has a view of the orbital arc.

Orient the antenna so that it comes up generally to the south (if located north of equator), north (if located south of equator).

3. Setup Quick Reference Using SkyScan



| Step | Function | Action | Display Page |
|------|--|--|--|
| 1. | Power up antenna | Turn on power at ACU | READY |
| 2. | Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP, [Code 0] Tech Setup, [CODE 13] |
| 3. | Clear existing satellite data. (Page 3.2) | From READY page Main 2x Arrow 2x + or - to ENTER + ENTER | READY TECH SETUP, [Code 13] SET TEST, [NONE] [CLEAR REF DATA] [cancel] [RUN NOW] READY |
| 4. | Initiate ScanSky function: | From SET TEST page + or - to ENTER + ENTER | SET TEST, [NONE] [SCAN Sky] [cancel] [RUN NOW] Initiates Sky Scan |
| 5. | Input reference satellites (Page 1.1) Select RefX satellite Select RefY satellite | From READY page: Arrow 1x + or - then ENTER + or - then ENTER | READY Set Ref XXX.X XXX.X |
| 6. | Input data satellite parameters. (Page 1.2) Toggle between SatA and SatB Input orbital position for SatA Input orbital position for SatB | From READY page Arrow 2x + or - then ENTER + or - then ENTER + or - then ENTER | READY SELECT DATA [SatA] or [SatB] XXX.X XXX.X |



Technical Manual DATA Presentation



IMPORTANT




There are four distinct groupings of functions in the operation of the TracStar Auxiliary Control Unit (ACU). This manual will discuss each of these groups (Ready Page, User Setup, Tech Setup and Diagnostics) individually.

During actual ACU operation, the various sections are selected by pushing the MAIN button the appropriate number of times thus moving "vertically" to select the desired group function. Hereafter, the block diagram will be shown for each individual function without the other groups functions being represented.

Regardless of what operation is displayed in the ACU display panel, returning to the MAIN or MASTER menu may always be accomplished by continually pressing MAIN until "READY:" appears.



MVS ACU Unit Display and Layout



| | |
|-------------------|--|
| START/ STOP | Places the antenna in operational mode (green LED on top) or standby (green LED on bottom) |
| DISPLAY SELECT | MAIN steps through the menu vertically → steps across the menu horizontally |
| MODIFY | ENTER to select or step through page + or - to modify selection |


Note: A Flashing Question Mark [---?---] in the display indicates an item has not yet changed in the process. Select the desired item with [+/-] then press enter.



Flashing Blocks indicate something has changed but not been stored. ENTER must still be pressed to move to the next item.



1.0 READY



- READY is the main or default page and appears once the system is powered up. The selected satellite and orbital position in degrees longitude is displayed. Positive degrees indicates west longitude, "-" or negative degrees indicates east longitude.
- To activate the system:
- Turn on power to the TracStar Power Supply.
- Press + and hold for 2 seconds to initiate a satellite acquisition. This can be done with the antenna in any position.
- Press - and hold for 2 seconds to stow. This can be done with the antenna in any position. Lower LED should be on.
- From the READY page the user can:
 - Press → move to the Select Satellite page.
 - Press **MAIN** move to User Setup.
- Note that when the system is in READY (standby) mode the bottom green LED is on. When the system is active the top LED is on.




1. Typical Acquisition Sequence

| Message Displayed | Description |
|-----------------------------------|---|
| POWER UP PLEASE WAIT | Power is being applied to the system |
| MONITOR CHECK PLEASE WAIT | The system is initiating its internal monitor software |
| LOADING PLEASE WAIT | The system is going through a momentary warm-up stage (3-5 seconds) |
| READY: (+ up – down) | The system is in standby mode waiting for instructions (green LED is on bottom): (a) Press + to initiate an acquisition (b) Press – to stow the antenna |
| RUN: (+/- stop) Startup @ XX | The system is active and has started an acquisition (green LED on top). NOTE: any time the system is active press + or – to place the system in standby. |
| RUN: (+/- stop) Compass XXX | The system is reading the compass and aligning. Shows relative compass sensor reading. |
| RUN: (+/- stop) Wait GPS 118 | The system is acquiring GPS signals Last digit shows number of GPS satellites acquired, +100 if locked |
| RUN: (+/- stop) SCAN XXX YYYYY | The system is scanning a reference satellite XXX is orbital position; YYY shows signal strength |
| RUN: (+/- stop) PEAK XXX YYY | The system is scanning the selected communications satellite |
| RUN: (+/- stop) Locked XXX YYY | The antenna is locked on the selected satellite |
| | To place the system in standby, press + or -, READY page will appear |



1.1 Set Reference Satellite



- The antenna system uses a reference satellite as part of the acquisition process.
- The Set Reference Satellite page allows the user to select up to two pre-programmed reference satellites from a stored library.
- The RefX is the primary and the RefY is the secondary. The secondary reference satellite will be used in case the primary satellite cannot be found, for example, signal blockage.



IMPORTANT

- NOTE: *Those satellites located west of 0° longitude are positive and those east of 0° are shown as a negative number.*



1.1 Set Reference Satellite (con't)

| Description | Action | Display |
|--|--|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13 Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Set Reference Page (Page 1.1) | From Ready Page: Arrow 1x | SetREF X[XXX.X] Y XXX.X |
| Reference X is the primary reference satellite. Select the appropriate reference satellite from the library. For USAdvb ONLY: {If reference satellite is unknown, select [auto]} | + or – then Enter (Press + to select known satellite or "auto", then Enter) | SetREF [XXX.X] Y [XXX.X] |
| Reference Y is the secondary satellite in case the primary satellite is not available, i.e., blockage. In some cases the RefY satellite will be used as a check during the acquisition. <i>If RefX is set as AUTO, then setting RefY to other than AUTO will cause the RefY location to be tried FIRST, followed by the AUTO list as needed.</i> | + or – then Enter (Press + to select known satellite or "auto", then Enter) | SetREF XXX.X Y [XXX.X] |





1.1 Set Reference Satellite (con't)

| Description | Action | Display |
|--|--|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13 Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Set Reference Page (Page 1.1) | From Ready Page: Arrow 1x | SetREF X[XXX.X] Y XXX.X |
| Reference X is the primary reference satellite. Select the appropriate reference satellite from the library. | + or – then Enter | SetREF XXXX.X Y [XXX.X] |
| Reference Y is the secondary satellite in case the primary satellite is not available, i.e., blockage. In some cases the RefY satellite will be used as a check during the acquisition | + or – then Enter | SetREF XXXX.X Y [XXX.X] |



1.2 Select Data Satellite



SELECT DATA [SatA]
A XXX.X B XXX.X

- The Set Data Satellite page allows the user to select the communications satellite of interest.
- The user can select up to two pre-programmed data satellites, SatA and SatB.
- The user can program the desired satellite by entering the orbital position in degrees longitude.



IMPORTANT

- NOTE: Satellites west of 0° longitude must be entered as positive values, satellites east of 0° longitude must be entered as negative values.




1.2 Select Data Satellite (con't)

| Description | Action | Display |
|---|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Set Satellite Page (Page 1.2) | From Ready Page: Arrow 2x | SELECT DATA [SatA] A XXX.X B XXX.X |
| When SatA is flashing, the antenna will acquire SatA. The orbital position for SatA is shown on the bottom row as well as on the READY page. Press ENTER to select SatA, or press + to change to SatB , then press ENTER. | + or – to [SAT A] or [SAT B] ENTER | SELECT DATA [SatA] A XXX.X B XXX.X SELECT DATA [SAT A] [A XXX.X] B XXX.X |
| Now the orbital position for SatA is flashing and the user can input the desired orbital position in degrees longitude. Press + or - until the desired value is reached then ENTER. | + or – to Data Sat Long ENTER | SELECT DATA [SatA] A XXX.X B XXX.X SELECT DATA SAT A A XXX.X [B XXX.X] |
| Now the orbital position for SatB is flashing and the user can input the desired orbital position in degrees longitude. Press + or - until the desired value is reached then ENTER. | + or – then Enter Main | SELECT DATA SatA A XXX.X [B XXX.X] READY |
| NOTE: Satellites west of 0° longitude must be entered as positive values, satellites east of 0° longitude must be entered as negative values. | | |




1.3 Polarity



- **Applies to MVS1200 with motorized feed assembly ONLY**
- The user is allowed to change the polarization of the receive frequency
- Allows the user to ReSCAN the existing selection of Satellite A / Satellite B frequency after changing the receive polarity





1.3 POLARITY (con't)

| Description | Action | Display |
|--|--|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Polarity Page (Page 1.3) FOR MVS1200 ANTENNAS ONLY | From Ready Page: Arrow 3x | POLARITY [VertDN] |
| After the code is entered, the word VertDN is flashing. The user can now manually input the desired polarity, VertDN or HorzDN. | + or – then Enter | POLARITY [VertDN] |
| ReUSE Freq is now flashing. The user can now manually select the ReUSE or ReSCAN options. <i>NOTE: ReSCAN is not intended to replace the Satellite Parameters / Section 2.2 of the manual. If the proper frequencies are in place for SatA and SatB, a simple ReSCAN can be used after changing polarity. If problems are encountered, refer to Section 2.2, reset the SatA and SatB frequencies to 10799 and the antenna will scan for the best available frequency.</i> | + or – then Enter  | [ReUSE Freq] [ReSCAN Freq] |

IMPORTANT



1.4 Manual GPS Input



- The antenna systems has an integrated GPS to aid in satellite acquisition. The Manual GPS page allows the user to select between the built in GPS (default) or manually input GPS coordinates in case the GPS is unavailable.



1.4 Manual GPS Input (con't)

| Description | Action | Display |
|--|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| GPS Normal Page (Page 1.4) | From Ready Page: Arrow 4x | GPS [NORMAL] |
| After the code is entered, the word NORMAL is flashing. The user can now manually input the GPS coordinates. | + or – then Enter | GPS [NORMAL] |
| MAN is now flashing, press ENTER to step to the latitude input. | Enter | Gps[MAN] LATXXX.XX LONG XXX.XX |
| LAT is now flashing, press + or – until the desired coordinate is reached, then press ENTER. | + or – then Enter | GpsMAN [LAT 22.86] LONG XXX.XX |
| LONG is now flashing, press + or – until the desired coordinate is reached, then press ENTER. | + or – then Enter | GpsMAN LAT 22.86 LONG [81.23] |




IMPORTANT

NOTES:

1. Coordinates are entered in degrees and decimals of degrees (vs. minutes and seconds)
2. Coordinates west of 0° longitude are positive, east of 0° are negative values.
3. Coordinates north of the equator are positive, south of the equator are negative.



1.5 Manual Compass Input



COMPASS NORMAL

- The antenna system has an integrated compass to aid in satellite acquisition. The Manual Compass page allows the user to provide the antenna with a north or south heading in case the compass is unavailable or heavily influenced by external magnetic fields.
- The Menu returns to the READY PAGE.




1.5 Manual Compass Input (con't)


| Description | Action | Display |
|---|--|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13 Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| COMPASS Page (Page 1.5) | From Ready Page: Arrow 5x | COMPASS [NORMAL] |
| After the code is entered, the word NORMAL is flashing. Press + or – to change to Manual input, then ENTER. | + or – then Enter | COMPASS [NORMAL] |
| The Display now prompts the user to jog the antenna to face or point south. The Jog function is described in section 2.1. | | COMPASS MANUAL JOG South, Start |
| Once the antenna is pointed south using the Jog function, press START and the system will initiate its scan from the manually input south position. | | |



2.0 USER SETUP




USER SETUP == >
#XXXXX Ver v.wxyZ

- USER SETUP contains several interactive and setup pages including antenna jog control and satellite parameter setup.
- The antenna serial number and the software version is shown on the bottom row.
- Press  to step to the Jog page or MAIN to step to the TECH SETUP page.



2.1 Jog



Jog [FAST 1.0] → ENT
A 0 E 0 ss 0

- Jog control enables the user to manually position the antenna in the azimuth, elevation and polarization axes. The jog step increment is flashing.
- Press to select FAST (2 Degree steps) or SLOW (1 Degree steps) jog increments.
- Press to select.



IMPORTANT

CAUTION:

DO NOT JOG THE ANTENNA IN AZIMUTH OR POLARIZATION WHILE IN STOW.

DO NOT DRIVE THE ANTENNA BEYOND ITS TRAVEL LIMITS IN ANY AXIS



2.1 Jog (con't)

| Description | Action | Display |
|--|--|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13 Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Jog Page (Page 2.1) | From Ready Page: Main 1x Arrow 1x | Jog FAST A XXX.XX |
| Jog Position is now flashing. The user can select FAST or SLOW jog increments. | + or – then Enter | Jog FAST A XXX.XX |
| The azimuth position is now flashing. The user can jog the antenna by pressing + for clockwise and – for counterclockwise. | + or – then Enter | Jog FAST 1.0 → ENT [A 0] E 0 P 0 |
| Now the elevation position is flashing. The user can jog the antenna by pressing + for up and – for down. | + or – then Enter | Jog FAST 1.0 → ENT A 0 [E 0] P 0 |
| Now the polarization position is flashing. When viewed from the rear of the dish, the user can jog the antenna by pressing + for clockwise and – for counterclockwise. | + or – then Enter | Jog FAST 1.0 → ENT A 0 E 0 [P 0] |

NOTES:


1. The user must press START/STOP to activate the antenna motors. The top green LED will flash when the motors are enabled.
2. DO NOT JOG THE ANTENNA IN AZIMUTH OR POLARIZATION WHILE IN STOW.
3. DO NOT DRIVE THE ANTENNA BEYOND ITS TRAVEL LIMITS IN ANY AXIS.



IMPORTANT



2.2 Satellite Parameters



| | | |
|------------------|-------|------|
| SatAf10700,11857 | | |
| 0 | 119.0 | sr28 |

- The Satellite Parameters page allows the user to view or edit the frequencies used to acquire the communications satellite.




2.2 Satellite Parameters (con't)


| Description | Action | Display |
|--|--|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13 Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Satellite Parameters Page (Page 2.2) | From Ready Page: Main 1x Arrow 2x | SatAf10799, 10799 [0] 119 sr28 |
| The user can toggle between SatA and SatB. To change to SatB, press + to switch to SatB. To change from SatB to SatA, press -. The orbital position of the selected satellite is displayed on the bottom row. | + or – then Enter | SatAf10799, 10799 [0] 119 sr28 |
| To input a new frequency for SatA press Enter then + or – to the desired frequency, then Enter. The default frequency is 10799. When the default is entered, the antenna will scan for the best frequency available. | + or – then Enter | SatA[f10799], 10799 0 119 sr28 |
| This is the secondary frequency and may be used by the antenna to verify lock or as a backup frequency, depending on the Lock Word (paragraph 2.4) | + or – then Enter | SatAf10799, [10799] 0 119 sr28 |
| sr is the symbol rate and should not be adjusted. | | |



2.3 Reference Satellite



| |
|---------------------|
| [Rs1] f10799, 10799 |
| 110.0 SS |



- The Reference Satellite page provides access to the available reference satellites so the user can:
 - Enter Reference Satellites
 - Delete Reference Satellites
 - Edit parameters
- Up to 12 reference satellites can be stored





2.3 Reference Satellite (con't)

| Description | Action | Display |
|---|--|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13 Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Reference Satellite Page (Page 2.3) | From Ready Page: Main 1x Arrow 3x | [Rs1] f10799,10799 XXX.X USDvB |
| The user can enter/edit the reference satellites from this page. When [RSX] is flashing the user can step to the next reference satellite with + or -. There can be up to 12 Reference Satellites stored. Select the desired Ref satellite number then Enter. | + or – then Enter | [RsX] f10799,10799 XXX.X USDvB |
| The orbital position is now flashing and can be edited. Press + or – to the desired value, then Enter | + or – then Enter | RsX f10799,10799 [XXX.X] USDvB |
| The primary frequency is now flashing. Use + or – to set the desired frequency or set to 10799 as default, then Enter. The default will be automatically updated when the frequency scan is run (para. 3.2 Set Test) | + or – then Enter | Rs2 [f10799],10799 XXX.X USDvB |
| Continued on Next Page | | |



2.3 Reference Satellite (con't)

| Description | Action | Display |
|---|-------------------|--|
| Carry Over From Page 29 | | |
| The backup frequency is now flashing. Use + or – to set the desired frequency or set to 10799 as default, then Enter. The default will be automatically updated when the frequency scan is run (para. 3.2 Set Test) | + or – then Enter | Rs2 f10799,[10799] XXX.X USDvB |
| The user can select a scan method that uses signal strength (SS) or frequency (Freq) or USDvB to acquire the Reference Satellite. | + or – then Enter | Rs2 f10799, 10799 XXX.X [USDvB] |
| If more Reference Satellites are desired, change to RsX then input the orbital positions and frequencies. <i>Repeat until all the applicable Reference Satellites are input.</i> | + or – then Enter | [RsX] f10799, 10799 XXX.X USDvB |



2.4 Peak/Re-reference/Lock Methods

| | | | |
|------|------|-------|---|
| Peak | ST | ReRef | Y |
| Lock | 1022 | | |

- This page gives the user the ability to:
 - change between SatA and SatB satellites without initiating a new acquisition sequence, i.e., skip the compass and reference satellite scan functions. The antenna will move directly between SatA and SatB
 - Set the Lock Method Word
- Upon Power Up the antenna will default as follows:
 - Peak: ST: As previously set
 - ReRef: Y
 - Lock Word: As previously set



2.4 Peak/Re-reference/Lock Method (con't)

| Description | Action | Display |
|---|--|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13 Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Peak / Re-reference / Lock Page (Page 2.4) | From Ready Page: Main 1x Arrow 4x | [Peak [ST] ReRef Y Lock 1022 |
| The antenna has two types of peaking, step track and criss-cross. Step Track is the default and required mode and should not be changed. Press Enter to step to ReRef{Y}. | Enter | Peak [ST] ReRef Y Lock 1022 |
| The user can set the antenna to change between SatA and SatB without repeating the compass and reference satellite scans. This should not be changed unless the user has a requirement to lock onto more than one satellite. | Enter | Peak ST [ReRef Y] Lock 1022 |
| The Lock Word sets the criteria by which the antenna identifies satellites. The choices are to use a transponder/carrier frequency or by signal strength. By modifying the Lock Word, certain conditions are set and must be met for the antenna to lock. | + or – then Enter | Peak ST ReRef Y [Lock 1022] |
| Note: The following are valid lock words. | 1233, 1133, 1036, 1022, 1032, 1023, 1222, 1233,1232,1223 and 10000 (DirectPoint Mode) | |



Peak ST ReRef Y
Lock [1022]

2.4 Peak/Re-reference/Lock Method (con't)

| 0 | 1 | 0 | 2 | 2 |
|----------------------------------|--------------------------|------------------------------------|---|------------------------------------|
| | Reference Satellite Scan | Reference Satellite Lock Condition | Reference Satellite Frequency Condition | Data Satellite Frequency Condition |
| | 0 = Signal Strength | 0 = AGC | 0 = Neither | 0 = Neither |
| 1 = DirectPoint Mode | 1 = Frequency | 1 = AGC & SNR | 2 = F1 or F2 | 2 = F1 or F2 |
| All Other parameters must be "0" | | 2 = SNR Only | 3 = F1 and F2 | 3 = F1 and F2 |
| | | | | 6 = Peak on B; Move to Sat A |

Example: 1022 is a decimal word and will set the following condition for acquisition of the Reference and Data Satellite:

1022 = When the antenna is scanning for the Reference satellite, it will use the frequency from the Reference Satellite Page (2.3). Alternatively, if the digit is set to 0, the antenna will scan for the Reference Satellite using signal strength.

1022 = 0 the AGC circuit of the internal receiver is used for a satellite lock indication. If the digit = 1, the lock indication is a combination of AGC and SNR (Signal Noise Ratio) readings. If the digit = 2, the lock indication is from SNR values only.

1022 = This digit sets the condition that the antenna must find either the primary or the secondary frequency (F1 or F2) on the reference satellite in order to confirm lock. Alternatively, if the digit is set = 3, F1 AND F2 will be confirmed in order for the antenna to lock.

1022 = This digit sets the condition that the antenna must find either the primary or the secondary frequency (F1 or F2) on the reference satellite in order to confirm lock. Alternatively, if the digit is set = 3, F1 AND F2 will be confirmed in order for the antenna to lock. *


If the last digit is set to = 6, the antenna will peak on Satellite B, then swing to Satellite A. Use this for extreme cases where there appears to be no transponder on the desired data satellite.

With DirectPoint™ the Lock Method Word can be set to 10000 to enable peaking on the desired satellite (Sat A or Sat B) without using a Reference satellite. In this mode the carrier data from the modem is used solely for acquiring and peaking on the satellite.



The valid lock words are: 1022, 1033, 1023, 1032, 1222, 1233, 1232, 1223 and 1036. Use 10000 for DirectPoint acquisition.*



3.0 TECH SETUP



MVS Display Layout



- TECH SETUP contains several interactive setup pages and the ability to enable/disable various sensors and motor drives. This page is password protected to prevent inadvertent or undesirable changes. The user must press + to Code 13, then ENTER to edit these pages.




3.0 TECH SETUP (con't)


| Description | Action | Display |
|--|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 READY |



3.1 Set Option





SET OPTION
[OPTION 0]




- Set Option is occasionally used for special functions.



3.2 Set Test



SET TEST
[NONE]

- There are several function available to the user in Set Test. Press the  to select the desired function. NOTE: The following tests do not have input parameters. They either RUN or NOT RUN a standard factory setup.

- NONE:
- SET PAZO: Sets pol axis azimuth offset
- MECH CAL: Mechanical calibration of antenna
- USA REF SETUP
- CLEAR REF DATA
- SCAN FREQ: Scans selected Reference Satellites for transponder/carrier frequencies that will be used in subsequent acquisitions.
- SCAN Sky: Scans the orbital arc for Reference Satellite positions, signal strength and frequency.
- EEP Save: Saves memory to EProm.
- SHOW MOVEs: Pre-programmed satellite acquisition simulation.



3.2 Set Test


| Description | Action | Display |
|---|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 READY |
| Set Test Page (Page 3.2) | From Ready Page: Main 2x Arrow 2x | SET TEST [NONE] |
| Press + or – until the desired function is shown: Set PAZO – Factory Direction Only MECH CAL – Factory Direction Only USA REF SETUP CLEAR REF DATA SCAN FREQ SCAN Sky EEP Save SHOW MOVES | + or – then Enter | SET TEST [NONE] |
| | + or - | SET TEST [CANCEL] SCAN FREQ |
| | Enter | SET TEST [RUN NOW] SCAN FREQ |



3.3 Level/Motor Control Page



LEVEL [ON] Az PL NOR
GYRO OFF EI NOR



- This page gives the user the ability to turn off the base level sensor and the azimuth, elevation and polarization motors. This would normally only be performed in a troubleshooting application.
- The GYRO option is not applicable to this antenna. Default setting is OFF.






3.3 Level/Motor Control (con't)

| Description | Action | Display BLUE indicates default setting |
|--|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 READY |
| Level / Motor Control Page (Page 3.3) | From Ready Page: Main 2x Arrow 3x | LEVEL [ON /OFF] Az PLNOR GYRO OFF EL NOR |
| The user can turn the base level sensor off, this would only be done during a maintenance or troubleshooting activity. | + or – then Enter | LEVEL [ON /OFF] Az PLNOR GYRO OFF EL NOR |
| The user can turn the azimuth and polarization motor off, normally only a troubleshooting function. | + or – then Enter | LEVEL ON Az PL [NOR /DIS] GYRO OFF EL NOR |
| The user can turn the elevation motor off, normally only a troubleshooting function. | + or – then Enter | LEVEL ON Az PL NOR GYRO OFF EL [NOR /DIS] |



3.4 Select Modem/Antenna/Pol



- The antenna has a serial interface for communications to selected modem types. The antenna can provide GPS information over this port.
- Press the + or – key to scroll through the pre-programmed modem models, make a selection and press ENTER.
- On the MVS1200 (1.2 Meter) Antenna with the Motorized Feed Assembly, Receive Polarization can be selected.




3.4 Select Modem/Antenna/Pol (con't)

| Description | Action | Display | MODEM TYPE | Supported Modems |
|--|---|--|------------|----------------------------|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 READY | NONE | |
| Select Modem / Antenna Page (Page 3.4) | From Ready Page: Main 2x Arrow 4x | Modem [iDirect] Ant 96 Remove | iDirect | Net Modem II Plus |
| The user can select from the following modem types for the GPS interface: None iDirect Linkstar Linkway AuxRemote | + or – then Enter | Modem [iDirect] Ant 96 Remove | Linkstar | Linkstar, EMS |
| The antenna type cannot be changed without factory direction. | Contact Factory | Modem iDirect Ant 96 Remove | Linkway | Linkway |
| MVS 1200 Antenna ONLY | | | Aux Remote | |
| The user can select the Receive Polarization for the antenna. Choices are: HorzDN VertDN | + or – then Enter | [HorzDN] | Com Tech | Com Tech SCPC |
| | | | Skylane96 | Skylane @ 9600 baud |
| | | | iNfiniti | 3000,5000, 7000 iDirect |



3.5 Move/RF_SAFE



Move[SAFE] RF_SAFE

EL 3.00 Stow EN

- There are several safety features built into the antenna:
- MOVE SAFE prevents any azimuth motion including jog commands below a pre-set elevation angle. This is to prevent jogging the antenna at too low of angles and possibility causing a mechanical interference.
- RF SAFE provides a Transmit Inhibit feature. If there is any motion command given to the antenna while it is locked onto a satellite, the transmitter will be inhibited prior to any motion of the antenna. The modem must have a DC block installed in the receive line to be valid.
- STOW SAFE will stow the antenna if any base motion is detected by the on-board sensors. This feature will automatically stow the antenna if the user drives off with the antenna deployed.




3.5 MOVE/RF_SAFE (con't)


| Description | Action | Display BLUE indicates default setting |
|--|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Move/RF/Stow Safe Page (Page 3.5) | From Ready Page: Main 2x Arrow 5x | Move [SAFE /ANY!] RF SAFE EL 3.00 Stow EN |
| Move [SAFE] prevents azimuth axis motion including jog commands below this pre-set limit to prevent accidental mechanical interference. Move [ANY] will disable the SAFE mode. | + or – then Enter | Move [SAFE /ANY!] RF SAFE EL 3.00 Stow EN |
| RF [SAFE] will inhibit LNB power thereby inhibiting transmit if a motion command is given to the antenna via the controller. RF [ANY] will disable the SAFE mode. | + or – then Enter | Move SAFE RF [SAFE /ANY!] EL 3.00 Stow EN |
| EL [X.XX] sets the low elevation angle for Move SAFE. Adjust with + or – until the desired value is reached. | + or – then Enter | Move SAFE RF SAFE [EL 3.00 /x.xx] Stow EN |
| Stow [En] is the auto stow feature designed to stow the antenna in the event of excessive base motion. This is a safety feature if the antenna is roof mounted and the vehicle begins to move with the antenna up. Stow [DIS] will disable the safe feature. | + or – then Enter | Move SAFE RF SAFE EL 3.00 Stow [EN /dis] |



3.6 Azimuth Stow/External Switch



AZ [Stow 7.50]
Ext EN



- The AZIMUTH STOW setting provides the offset for the angular distance from the azimuth reference switch to the desired azimuth stow position.
- The Enable/Disable setting enables or disables the optional stow switch that is located on the antenna.




3.6 Azimuth Stow Setting

| Description | Action | Display BLUE indicates default setting |
|--|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 READY |
| Azimuth Stow / External Switch Page (Page 3.6) | From Ready Page: Main 2x Arrow 6x | AZ [Stow 7.5] Ext EN |
| The azimuth stow setting determines the offset for the angular distance from the azimuth axis reference switch to the desired azimuth stow position. + or – will change the angle. This is set in the factory. | + or – then Enter | AZ [Stow 7.5] Ext EN |
| Ext EN indicates whether the pedestal start/stow switch is enabled or disabled. Press + or – to change the selection, then Enter. | + or – then Enter | AZ Stow 7.5 Ext [EN/dis] |



3.7 USAdvb




[Mid East] LO 10.75
Fb L 11.2/H 11.7

- The LNB Setup page allows the user to:
 - Select the region of the world that the antenna is located in
 - Input the local oscillator frequency of the LNB in use
 - Input the receive frequency band corresponding to the transponder and LNB in use.
 - Note: these are the frequencies that are used during the antenna scan.






3.7 USAdvb

| Description | Action | Display BLUE indicates default setting |
|---|---|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| LNB Setup Page (Page 3.7) | From Ready Page: Main 2x Arrow 7x | [USAdvb] LO 10.75 Fb L 11.2/H 11.7 |
| The antenna must be set to USA, USAdvb, Mid East or Europe. Press + to edit then Enter. <i>USAdvb is the preferred setting in the USA, due to the type of satellite typically used as a reference. Mid EAST and EUROPE have the same internal software functions, either will work in either location.</i> | + or - then Enter | [USAdvb] LO 10.75 Fb L 11.2/H 11.7  |
| Set the LNB Local Oscillator frequency using + or -, then Enter | + or - then Enter | Mid East [LO 10.75] Fb L 11.2/H 11.7 |
| Set the low end of the frequency band in use with + or -, then Enter. | + or - then Enter | Mid East LO 10.75 Fb [L 11.2]/H 11.7 |
| Set the high end of the frequency band in use with + or -, then Enter | + or - then Enter | Mid East LO 10.75 Fb L 11.2/[H 11.7] |
| | | |

IMPORTANT



3.8 LNB GAIN



- The LNB Gain page allows the user to:
 - Adjust the gain of the LNB as seen by the antenna controller's built in signal strength measurement (SS).
 - Enter a LNB noise offset as seen by the antenna controllers built in signal strength measurement (SS).




3.8 LNB GAIN


| Description | Action | Display BLUE indicates default setting |
|---|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| LNB GAIN Page (Page 3.8) | From Ready Page: Main 2x Arrow 8x | [USAdvb] LO 10.75 Fb L 11.2/H 11.7 |
| The user may wish to adjust the LNB gain as measured by the built in tuner: Gain = 100, nominal setting Gain = 50, ½ of nominal gain Gain = 200, double the nominal gain When adjusting the gain, monitor the signal strength number in the lower right. Increasing the gain will increase the signal level. | + or – then Enter | LNB [GAIN 100] Offset 0 XXX |
| The user may wish to adjust the LNB offset as measured by the built in tuner. Adjust the offset when the antenna is pointed at a cold sky. Adjusting the offset should minimize the signal strength number when the antenna is looking at cold sky. | + or – then Enter | LNB GAIN 100 [Offset 0] XXX |



4.0 DIAGNOSTICS



DIAG No LOG ==>
St XX ssXX YYY



- The Diagnostics section includes information on antenna pointing angles, level sensor readings, GPS data and the ability to set correction factors for the three axes.
- “No LOG” and “LOG try” are messages unique to Idirect Modems and a log-in process.
- St XX indicates the tracking state of the antenna.
- ssXX indicates the current signal strength reading.
- YYY is tuner signal to noise (>100 is locked) ratio.




4.A Axis Angles

A 246.00 E 28.70



Ap 44.6 Ep 27.77

- The DIAGNOSTICS A page indicates the azimuth and elevation angles of the antenna.
- The top row shows the antenna Az and El angles relative to the earth (azimuth only valid after lock on)
- The second row Ap and Ep indicate the Az and El angle relative to the pedestal coordinates, i.e., the azimuth stow angle is zero degrees. El is only valid above -10 degrees.






4.B B Page



- The DIAGNOSTICS B page displays the polarization angle of the antenna.




Communications from modem-NONE


- The DIAGNOSTICS C page displays modem messages when connected to an iDirect modem only.



4.D Scan Hits




2125082 0000000
0000000 0000000



- The DIAGNOSTICS D page indicates satellites that were “seen” during the acquisition and alignment of the antenna.
- Each of the four groups of seven digits is as follows:
 - 1st - 3 digits - azimuth angle (example 212)
 - Next two digits - elevation angle (example 50)
 - Last two digits signal – strength (example 82)




4.E Tilt Angles



| | | | |
|-----|-----|-----|-----|
| Eba | 0.8 | Afx | 0.3 |
| Rba | 1.4 | Rfx | 2.2 |


| | | | |
|-----|-----|-----|-----|
| Elv | 4.0 | Afx | 1.7 |
| Rlv | 1.5 | Rfx | 1.4 |



- The values on the DIAGNOSTICS E Page are the pedestal base tilt angles as measured by the tilt sensor.
 - Eba = elevation base angle
 - Rba = roll base angle
 - Afx = azimuth adjustment due to base tilt
 - Rfx = pol adjustment due to base tile
 - Elv = raw (unfiltered) el base angle reading
 - Rlv = raw (unfiltered) roll level reading



4.F Axis Position Transducer Readout




| | |
|----------|---------|
| FpotRead | Ar15467 |
| Er 13364 | Rr11517 |

- The DIAGNOSTICS F page is the analog position transducer reading from the azimuth and elevation axis.
- Ar = azimuth reading
- Er = elevation reading
- Rr = (not used)



4.G GPS Data




- The DIAGNOSTICS G page provides the GPS data as follows:
- GPSok indicates the GPS signal is acquired

- LAT 28.56 indicates the current latitude of the antenna.
- MagD 5.10 indicates the magnetic deviation
- S108: 100 indicates GPS lock and 8 indicates the number of GPS satellites being received.
- Long 81.41 gives the longitude position of the antenna.



4.H Axis Zero Offsets



```

HsetZero [Ac12794]
Ec15180 Rc13698
  
```

- The DIAGNOSTICS H page allows the user to set the center value for each of the transducers as seen on the F page.
- Ac is the azimuth center value used to set azimuth 0 degree angle (stow position).
- Ec is the elevation center value used to set elevation 45 degree angle.

▪ Rc (not used)




4.H Axis Zero Offsets (con't)

| Description | Action | Display |
|--|---|--|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 READY |
| Axis Zero Offsets Page (Page 4.8) | From Ready Page: Main 3x Arrow 8x | HsetZero [Ac12794] Ec15180 Rc 13698 |
| When Ac (azimuth center) is flashing, the user can press + or – to change the azimuth value, then Enter. | + or – then Enter | HsetZero [Ac12794] Ec15180 Rc 13698 |
| When Ec (elevation center) is flashing, the user can press + or – to change the azimuth value, then Enter. | + or – then Enter | HsetZero Ac12794 [Ec15180] Rc 13698 |
| Rc = Not Used | + or – then Enter | HsetZero Ac12794 Ec15180 [Rc 13698] |



4.1 Axis Offsets



I[co -3.5] Eo -.28
Paz -.38 Po 0.00

- The DIAGNOSTICS I page allows the user to view and set offsets in degrees for each axis.
- Co is the compass offset, this correction is self learning and updates itself on each acquisition.
- Eo is the elevation offset after each acquisition.
- Paz is the boresight offset for the RF beam.
- PI is the polarization adjustment.



4.1 Axis Offsets (con't)


| Description | Action | Display |
|---|---|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Axis Zero Offsets Page (Page 4.9) | From Ready Page: Main 3x Arrow 9x | I [co -3.5] Eo -.28 Paz -.30 Po 0.00 |
| Co is the compass offset and updates automatically after each acquisition. The user should not change this value. | Enter | I [co -3.5] Eo -.28 Paz -.30 Po 0.00 |
| Paz is the boresite offset for the RF beam. This value is set in test and should not be changed by the user. | Enter | I co -3.5 Eo -.28 [Paz -.30] Po 0.00 |
| Po is an offset for the polarization axis. An offset can be permanently input by the user if necessary. | + or – then Enter | I co -3.5 Eo -.28 Paz -.30 [Po 0.00] |



4.J Azimuth Scan Width

```
J sw 40.00
pmz -3.75 c 0.00
```

- The Diagnostics J page allows the user to set the width of the azimuth scan during the initial reference satellite acquisition.
- The default value is 40.0 degrees.
 - The max value is 100 degrees
 - The min value is 10 degrees.






4.J Azimuth Scan Width (con't)

| Description | Action | Display |
|--|---|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Azimuth Scan Width Page (Page 4.10) | From Ready Page: Main 3x Arrow 10x | [Sw 40.00] pmz -3.75 |
| The user can adjust the azimuth scan width from 10 to 100 degrees. 40 is the default. | + or – then Enter | [Sw 40.00] pmz -3.75 |
| | | Sw 40.00 [pmz -3.75] |



4.K SFE SFR

K sfe1220 sfr1220



- These values are the base angle level span calibrations for the e (elevation) and r (roll) tilt.




4.K SFE SFR (con't)

| Description | Action | Display |
|--|---|---|
| Set Code (enables editing) (Page 3.0) | From READY page Main 2x + to code 13, Enter Main 2x | READY TECH SETUP Tech Setup CODE 13 |
| Azimuth Scan Width Page (Page 4.11) | From Ready Page: Main 3x Arrow 11x | K sfe1220 sfr1220 |



4.L Axis Diagnostics





| | | | |
|-------|------|---|--------|
| LazEr | 0.00 | D | 0 |
| C | -1 | E | 401296 |

- Internal Readings from azimuth axis.
- Perform manual jog of the azimuth axis when "RUN" is 'on' and +/- buttons are depressed.
 - Er – Servo Position Error
 - D – DAC Value +/- 120
 - C – Current Value +/- 100
 - E – Encoder Counts



4.M Axis Diagnostics





| | | | |
|-------|------|---|-------|
| MelEr | 0.00 | D | 0 |
| C | -1 | E | 81424 |

- Internal Readings from elevation axis.
- Perform manual jog of the azimuth axis when "RUN" is 'on' and +/- buttons are depressed.
 - Er – Servo Position Error
 - D – DAC Value +/- 120
 - C – Current Value +/- 100
 - E – Encoder Counts



4.N Axis Diagnostics




| | | | |
|-------|------|---|--------|
| NplEr | 0.00 | D | 0 |
| C | -1 | E | 165542 |

- Internal Readings from pole axis.
- Perform manual jog of the azimuth axis when "RUN" is 'on' and +/- buttons are depressed.
 - Er – Servo Position Error
 - D – DAC Value +/- 120
 - C – Current Value +/- 100
 - E – Encoder Counts



4.0 Axis Diagnostics


| | |
|------------|--------|
| O AZ>EncSf | 2468 |
| Kp 50 | Ki 120 |



- Azimuth Encode Scale Factor
- Setup Readings for Azimuth Axis
- Kp and Ki are servo loop data



4.P Axis Diagnostics





| | |
|----------|--------|
| P AZ>Psf | 1800 |
| BL 50 | VF 100 |

- Azimuth Pot Scale Factor
- Additional Setup Readings for Azimuth Axis
- BL and VF are servo parameters



4.Q Axis Diagnostics



| | |
|------------|-------|
| Q EL>EncSf | 1252 |
| Kp 30 | Ki 25 |


- Elevation Encode Scale Factor
- Setup Readings for Elevation Axis
- Kp and Ki are servo loop data



4.R Axis Diagnostics



| | |
|----------|-------|
| R EL>Psf | 987 |
| BL 50 | VF 60 |

- Elevation Pot Scale Factor
- Additional Setup Readings for elevation axis
- BL and VF are servo parameters





4.S Axis Diagnostics





| | |
|------------|-------|
| S PL>EncSf | -409 |
| Kp 50 | Ki 50 |

- Pole Encode Scale Factor
- Setup readings for Pole axis
- Kp and Ki are servo loop data



4.T Axis Diagnostics



| | |
|----------|------|
| T PL>Psf | 2358 |
| P1 10 Mz | 0 |

- Pole Pot Scale Factor
- Additional setup readings for pole axis



TROUBLESHOOTING

- Antenna has no power.

Turn off Power. Check the power cord on the ACU and or the rack mount control panel. The antenna receives its power from one of these two respective locations. Check the antenna end of the grey cable with the black connectors as well. Reapply Power. Restore Power.

- OBSTRUCTIONS

Ensure there is a clear unobstructed view towards the equator relative to the antenna's position.

- Antenna Not Responding

When using the handheld controller, ensure the RJ11 (phone cord) connection is properly seated in the ACU and the handheld device.

- REF SAT NOT FOUND

Select an alternate reference satellite (refer to page xx) and begin the acquisition process again. Should the message still occur, move the antenna base in a 90° arc and check the leveling of the antenna. Auto-correction features in the software will accommodate up to $\pm 10^{\circ}$ of error in the mounting plane of the antenna.

- Skyscan

Skyscan can be engaged to find all available satellites in the sky. Refer to the operating manual for instruction on using Skyscan.

- Waiting Log On (iDirect)

The TracStar controller 'logs' into the iDirect modem, when iDirect modem is selected. Make sure the DB9-RJ45 cable is in place between the controller and the modem, as this serves as the communication link. If communication still fails, set modem to NONE to allow antenna to lock onto satellite.



5: Description of System

TracStar MVS750 / AvL Model 750 iMoVSAT three-axis positioner

TracStar Controller

The complete system weighs approximately 95 lb. depending upon the options selected.

General

The Model MVS750 / iMoVSAT antenna system is an elevation over azimuth positioner featuring the simple, rugged Roto-Lok® drive system that produces very low backlash, high stiffness, and high reliability. It is driven by a low backlash gearbox with DC motors and all drive components are high-strength steel encased in lubricated-for-life housings, resulting in the most reliable, no-maintenance system with the minimum of weight. The reflector is a 75 cm equivalent Channel Master illuminated by a corrugated horn. The options for the placement of the transmitter vary depending upon the size: A 1 - 4 watt BUC can be installed on the feed boom.

RF System

The offset reflector/feed system produces co-polarization patterns that easily meet the FCC Section 25.209 requirements beyond 1.72 degrees in the transmit band and 1.95 degrees in the receive band. It is also fully compliant with the ITU Recommendation for international use.

Roto-Lok Drive System

The patented Roto-Lok drive system utilizes highly reliable aircraft control cables in a redundant configuration to achieve a lightweight, very stiff drive system with zero backlash. This high-tech performance is achieved using low-tech components - by simply wrapping the cable around the drive capstan several times before wrapping the larger drive drum. This method results in a minimum free-length of cable. The load cable on the main drum is exponentially reduced as it is wrapped around the drum. Therefore, the total elongation of the cable under load is minimized. The Roto-Lok system has up to 10 times less backlash than that of comparable gear systems. The cables are pre-tensioned and spring-loaded at the main drum attachment point, which eliminates backlash at installation and from any unexpected cable stretch in the future.



Secondary Drive System

The Az and El Roto-Loks are driven by a low backlash worm gear set with a 15:1 and 30:1 ratio respectively. The low backlash of the worm gear drive is reduced further by the Roto-Lok drive ratio. This results in a lash equivalent of only .1° in azimuth and .2° in elevation as seen by the reflector system. The gear sets are encased in a sealed housing allowing for continuous lubrication in synthetic oil, maximizing gear efficiency and minimizing wear.

Motor Drives

Lightweight, reliable, servo-quality DC motors with integral gearbox are used for Az, El, and Pol drives. The motors are also equipped with optical encoders that provide precise speed and positioning control, ensuring smooth operation when peaking the antenna. The 24V DC design provides current-limiting torque control and will allow for vehicle battery operation if necessary.

Controls

The antenna control system is produced by TracStar Systems and is integrated exclusively with the Roto-Lok pedestal assembly. The controller includes a tunable receiver, GPS system, and flux-gate compass. The main portion of the controller is located on the antenna positioner, placing it close to the optical encoders. The power supply and hand-held controller are separate and can be placed up to 25 feet away without special hardware. Special control cables can be obtained to place the power supply and hand-held up to 150 feet away from the antenna.

The TracStar controller was developed to achieve one-button, auto-acquisition of the satellite signal 100% of the time using a proprietary method. The controller peaks the antenna on the data satellite with greater accuracy than a human can achieve, thus assuring that there is no chance of adjacent satellite interference. Primary and secondary reference satellite menus and data satellite menus are available for an untrained operator. Any data satellite can be selected or pre-programmed by a trained operator. Semi-automatic modes are available in case of failure of GPS or a flux-gate to provide acceptable manual input of case heading and/or latitude and longitude. An *Auto-Select* mode is available for reference satellite selection in the TracStar software (domestic CONUS use only). The TracStar control system will work on any Ku Band satellite.

Construction

Except for the drive components and bearings, all components are aluminum, stainless steel or plastic to prevent rusting.

¹ Roto-Lok is a registered trademark of Sagebrush Technologies, Inc. All Rights Reserved.




6: General Deploy and Assembly Instructions

The TracStar MVS750 / AvL Model 750 positioner has been fully tested with the TracStar controller prior to shipment. All position feedback, limit sensing, limit switches, and motor speeds have been calibrated or set. The positioner needs only to be deployed and the coax and control cables connected to the controller.

1. Model 750 shown in stowed position (Figure 1)

Figure 1



2. Connecting the coax cable first, make the appropriate electrical connections. (Figure 2.)

Figure 2





3. Press “+” on TracStar hand-held controller (Figure 4) and hold for 3 seconds until unit begins deploying.
4. Figure 3 shows the unit fully deployed.

Figure 3



Controller Operating Instructions

1. To activate system, turn on power to the TracStar Indoor Unit (IDU). The display should read "Ready".
2. Press the "+" key to begin satellite acquisition.
3. To stow the antenna, press and hold the "-" key for 3 seconds. To insure that transmit is disabled, there is a 3-second delay before the antenna begins to stow.
4. The user may stop the motion by pressing the Start/Stop, + or - key at any time, either during an acquisition (Display reads "Run") while locked or during a stowing operation (Display reads "Stow").



Complete operating instructions can be found in the TracStar Controller Operating Instructions included in this manuals Index.



7: Azimuth Positioning System

Azimuth Bearing

The azimuth platform sits on top of a ball bearing platform with a dynamic and static moment capacity of over four times the worst-case wind-load specification. The assembly is surrounded by a double seal to protect the bearing platform, which is permanently lubricated. This rests on the azimuth drum and the azimuth cables wrap around the drum and capstan. Because of the excess capacity, low rpm and low number of cycles compared to the bearings B10 design life, no wear is expected. No maintenance should be required over the life of the positioner.

Azimuth Gearbox

The azimuth gearbox is a low backlash worm gearbox. The worm gear drive isolates any backlash in the motor drive from the system. In addition, since it is a 15:1 ratio, it will not back drive, thus eliminating any need for a brake on the drive train. The motor drives the input worm via a quill/female hole and square key. The azimuth capstan is secured to the bore of the output shaft with a square key. The gearbox contains synthetic oil. Because of the design capacity of the gearbox, low rpm and comparative limited cycles experienced by the system, no wear or maintenance is expected.

Azimuth Motor

The azimuth drive motor is a servo quality and 24DC motor with integral 19.7:1 spur gear train. The motor armature rotates at up to 4000 rpm causing a high-frequency noise that will vary, depending on the loading condition of the motor. An optical encoder is mounted to the other end of the motor output shaft to provide real-time positional information to the TracStar controller. The maximum gearbox output speed is 253 rpm. The output shaft is "D" shaped with a special adapter with a slot for a square key. Since the low backlash worm gear drive isolates the backlash from the motor, any backlash between the shaft adapter, square key, or motor gear train will never be seen by the reflector boresight. Any backlash at any of these points is of no consequence to the system performance. No maintenance or wear of the elevation motor is expected.

Azimuth Roto-Lok Cable Drive

The patented azimuth Roto-Lok drive produces a drive system with zero backlash, high stiffness, no wear, no lubrication, and maximum reliability. The system consists of three 1/16 9x17 stainless steel aircraft control cables, reverse-wrapped twice around the capstan with solid connections on one end and high force, Belleville springs on the other end occurring at the azimuth spring block. One cable has the capacity to withstand an 80 mph wind load. The additional cables are used to



provide increased stiffness and drive redundancy. ***If a cable becomes damaged during usage, merely cut off the cable and continue to use the positioner. You can replace the cable at your maintenance facility whenever time permits.***

The cables are sized to last the life of the positioner. No replacement from wear is expected. The spring package at one end will automatically compensate for any elongation of the cable. At installation, the Belleville springs are collapsed until no "air" is seen between the springs. You should check this condition yearly to account for the slow settling of the cable strands. Use a 3/8 box-end wrench to tighten the nut. ***Be sure not to over tighten.***

Azimuth Position Feedback

The azimuth position feedback is produced by a 10-turn, 1K-ohm potentiometer driven by the output shaft of the worm gearbox. In addition, an optical encoder is mounted to the output shaft on the motor and provides redundant feedback on azimuth position. The encoder also provides precise redundant feedback on unit's position relative to zero degrees starting position. The potentiometer is mounted on an angle plate that is mounted to the azimuth gearbox. A gear mounted to the potentiometer is driven by a pinion on the output shaft of the gearbox. The potentiometer is mechanically set at the one-half travel position when the azimuth cable position is at zero degrees. The azimuth stow switch is a magnetic proximity switch mounted in the az platform. The limits are controlled by using inputs from the potentiometer and optical encoder together and are set in and controlled by the TracStar controller. The azimuth drive has the mechanical capability of $\pm 400^\circ$ or $\pm 200^\circ$ from stow position.

8: Elevation Positioning System

Elevation Pivot Assembly

The elevation pivot assembly consists of two elevation drum assemblies pivoting between two clevis blades that house the high-tech, no-lubrication required, plastic bushings. No wear or maintenance is expected.





Elevation Gearbox

The elevation gearbox is a low backlash worm gearbox. The worm gear drive isolates any backlash in the motor drive from the system. In addition, since it is a 30:1 ratio, it will not back drive eliminating any need for a brake on the drive train. The motor drives the input worm via a quill/female hole and square key. The dual elevation drive shafts are driven with a square key. The elevation capstan is secured to the dual output shafts with a cap screw that clamps to the output shaft. The gearbox contains synthetic oil. Because of the design capacity of the gearbox, low rpm and comparative limited cycles experienced by the system, no wear or maintenance is expected.

Elevation Motor

The elevation drive motor is a 24V DC motor with integral spur gear train. The motor armature rotates at up to 4000 rpm causing a high frequency noise that will vary depending on the loading condition of the motor. An optical encoder is mounted to the other end of the motor output shaft to provide real time positional information to the TracStar controller. The maximum output speed is 133 rpm. The output shaft is a standard keyed shaft. The output torque capacity of the motor is rated for the operational wind load. Since the low backlash worm gear drive isolates the backlash from the motor, any backlash between the square key and motor gear train will never be seen by the reflector boresight. Any backlash at any of these points is of no consequence to the system performance. No maintenance or wear of the elevation motor is expected.

Elevation Roto-Lok Cable Drive

The patented azimuth Roto-Lok drive produces a drive system with zero backlash, high stiffness, no wear, no lubrication, and maximum reliability. The system consists of eight 1/16 9x17 stainless steel aircraft control cables, reverse-wrapped three times around the capstan with solid connections on one end and high force, Belleville springs on the other end occurring at the elevation cable termination block.

Four cables have the capacity to withstand an 80 mph wind load. The additional cables are used to provide increased stiffness and drive redundancy. ***If a cable becomes damaged during usage, merely cut off the cable and continue to use the positioner. You can replace the cable at your maintenance facility whenever time permits.***

The cables are sized to last the life of the positioner. No replacement from wear is expected. The springs package at one end will automatically compensate for any elongation of the cable. At installation, the Belleville springs are collapsed until no "air" is seen between the springs. You should check this condition yearly to monitor the slow settling of the cable strands.



Elevation Position Feedback

The elevation position feedback is produced by an electronic clinometer and encoder mounted on the output shaft of the motor. The clinometer has a resolution of 0.1 degrees with the accuracy/linearity of 1% of the 0-45° range and monotonic in the 45-90° range. The clinometer is rated for an outdoor environment. The encoder also provides precise feedback on the unit's position during operation. The limits are controlled by using inputs from the clinometer and optical encoder together and are set in and controlled by the TracStar controller. The clinometer is mounted on a bracket under the pol gear cover. The clinometer is covered with an aluminum cover to protect it from the mechanical damage and provide additional weather protection.

9: Polarization Feed and Drive Assembly

General

The feed assembly consists of the feed boom, feed housing, RF components and polarization drive. The feed boom is pivoted at the bottom of the reflector. The feed assembly is mounted to the feed boom.

Polarization Drive

The polarization drive motor is a 24DC gear motor. It is attached to the polarization gearbox. Polarization setting is accomplished by rotation of the reflector.

Polarization Gearbox

The azimuth gearbox is a worm gearbox. The worm gear drive isolates any backlash in the motor drive from the system. In addition, since it is a 30:1 ratio, it will not back drive, thus eliminating any need for a brake on the drive train. The gearbox contains synthetic oil. Because of the design capacity of the gearbox, low rpm, and comparative limited cycles experienced by the system, no wear or maintenance is expected.

Polarization Roto-Lok Cable Drive

The patented azimuth Roto-Lok drive produces a drive system with zero backlash, high stiffness, no wear, no lubrication, and maximum reliability. The system consists of two 1/16 9x17 stainless steel aircraft control cables, reverse-wrapped twice around the capstan with solid connections on one end and high force, Belleville springs on the other end occurring at the polarization spring block. One cable has the capacity to withstand an 80 mph wind load.



The additional cables are used to provide increased stiffness and drive redundancy. ***If a cable becomes damaged during usage, merely cut off the cable and continue to use the positioner. You can replace the cable at your maintenance facility whenever time permits.***

The cables are sized to last the life of the positioner. No replacement from wear is expected. The springs package at one end will automatically compensate for any elongation of the cable. At installation, the Belleville springs are collapsed until no "air" is seen between the springs. You should check this condition yearly to monitor the slow settling of the cable strands.

Polarization Position Feedback

The polarization position feedback is produced by the optical encoder mounted on the output shaft on the motor. The polarization stow and limit switch is mounted under the polarization platform and is accessible under the pol cover. The switch is fixed to a plate and is actuated by a rotation cam. The limits are controlled by using inputs from switches and optical encoder together and are set in and controlled by the TracStar controller. Pol stow is achieved by activating the stow switch mounted on the polarization cam. The polarization drive has the mechanical capability of $\pm 75^\circ$ or $\pm 95^\circ$.





10: Preventative Maintenance

Pedestal

General

The TracStar MVS750 / AvL Model 750 iMoVSAT is constructed to require a minimum amount of regular maintenance.

The following 21-Point Check List should be undertaken on a regular basis and can be rectified in the field:

21 Point Check List

1. Any small chips on the reflector front surface should be cleaned, filled with aluminum-loaded car body filler, rubbed down, primed and touched in with two-pack polyurethane paint.
2. The feed horn should be checked for cracks or damage.

Azimuth:

3. Check for unusual noise in the azimuth bearing, azimuth gearbox, and azimuth motor
4. Run in azimuth and check for unusual noise in azimuth motor
5. Check position of azimuth drive cables on capstan at 0°# Az
6. Check drive cables for damage
7. Run both Az limits and observe cable tracking
8. Check for excessive backlash in gearbox
9. Inspect cable terminations
10. Inspect Az potentiometer

Elevation:

11. Check for unusual noise in elevation pivot bushings and elevation gearbox
12. Run in elevation and check for unusual noise in elevation motor
13. Run up to limit
14. Check tracking of elevation drive cables
15. Check drive cables for damage
16. Check for excessive backlash in gearbox

Polarization:

17. Check for unusual noise in polarization pivot bearings and polarization gearbox
18. Run in polarization and check for unusual noise in polarization motor



19. Check tracking of polarization drive cables
20. Check drive cables for damage
21. Check for excessive backlash in gearbox

Spare/Replacement Parts

Since no wear or maintenance is expected, only electrical parts are recommended as spares. These parts will not fail from activity, but may fail from environmental exposure.

Optional:

| Description | Manufacturer | Manufacturer's Part # |
|--------------------|---------------------|------------------------------|
|--------------------|---------------------|------------------------------|

| | | |
|------------------------|--|-----------------------|
| Limit Switch Omron | | D2VW-5L2A-1HS |
| Potentiometer, 1k, 10T | | Spectrol 01F8239 |
| Proximity Switch | | CDI PS811 |
| Clinometer | | Spectron 02110002-000 |
| Spare Drive Cable Kit | | AvL Technologies |
| Elevation Motor | | Pittman GM9234E521 |
| Azimuth Motor | | Pittman GM9236E522 |
| Polarization Motor | | Pittman GM8724J199-R1 |



Appendix A – Data Sheets

Data Sheets for TracStar Products

MVS750 SERIES Mobile Broadband Satellite Communications

The MVS Series from TracStar allows non-skilled personnel to operate mobile Very Small Aperture Terminal (VSAT) satellite communications equipment enabling the user to access any broadband application over satellite.

The MVS Series antennas are typically owned and operated by:

- ▶ Corporations with remote or mobile office and monitoring applications
- ▶ Federal, state and local government agencies for law enforcement, emergency response and homeland security communications
- ▶ Military rapid deployment, SATCOM on the pause applications

With TracStar's MVS Series antennas, users enjoy the same reliable, secure, high-speed IP based data communications they are accustomed to in the office, while mobile. Users can get connected Anywhere/Anytime for applications such as:

- ▶ Secure, high-speed digital communications
- ▶ High-speed Internet access
- ▶ Voice and Fax communications
- ▶ Teleconferencing
- ▶ Wide area private network extension
- ▶ Video broadcasting



The MVS Series of auto-acquisition antennas feature:

- ▶ Automatic satellite acquisition with a single button push
- ▶ Rapid deployment and operation on every Ku-band satellite, worldwide
- ▶ Works with every satellite modem
- ▶ TracStar Technology eliminates the need for:
 - ▷ Special test equipment for alignment
 - ▷ Computers or peripheral equipment to operate the antenna
 - ▷ Phone calls to network operators or service providers

Every antenna comes equipped with the following standard equipment:

- ▶ High precision and stiffness, low backlash drive system
- ▶ Built-in GPS and compass
- ▶ Built-in satellite receiver
- ▶ Built-in level sensor
- ▶ Automatic polarization alignment
- ▶ Safe and easy installation, no calibrations required



*Convert Any Vehicle to a Mobile
Wireless Broadband Hot-Spot*



Broadband Anywhere - Anytime

MOBILE WIRELESS BROADBAND
HIGH SPEED DATA - INTERNET - VOIP - FAX - VIDEO



MVS 750 / 750P Specifications



MAIN Saddle UK
The MVS750 will connect from almost any satellite location or via the internet. The main part of the antenna will not be affected by rain, snow or other weather conditions. The antenna is designed to operate in temperatures as low as -40°C and as high as 60°C. The antenna is made of stainless steel and is completely corrosion resistant. The antenna is made of stainless steel and is completely corrosion resistant. The antenna is made of stainless steel and is completely corrosion resistant.




Easy deployment
Easy to transport into any vehicle. The antenna is made of stainless steel and is completely corrosion resistant. The antenna is made of stainless steel and is completely corrosion resistant. The antenna is made of stainless steel and is completely corrosion resistant.

OPTIONS




Control Panel
The control panel is made of stainless steel and is completely corrosion resistant. The control panel is made of stainless steel and is completely corrosion resistant. The control panel is made of stainless steel and is completely corrosion resistant.



Modular MVS750P
The MVS750P is a modular antenna system. It is made of stainless steel and is completely corrosion resistant. The MVS750P is a modular antenna system. It is made of stainless steel and is completely corrosion resistant. The MVS750P is a modular antenna system. It is made of stainless steel and is completely corrosion resistant.


General Usage Position



Stowed Position



MVS 750 Antenna POD



Reflector
Size: 75cm Hubband electrical (88cm on vehicle x 67cm high)
Material: 3-axis Polished Aluminum Elevation over Azimuth
Polarization: Linear, Co or Cross Polarized

Travel
Azimuth: 40° or ± 20° from Stow Position
Elevation: 0-65° (+180m Position
Polarization: ±65°

Travel Velocity
Swing/Deploying: Azimuth
Manual Log: Elevation
Electrical: Azimuth
Manual Log: Elevation

Electrical Interface
RF: 750 Tx / Rx Type F Connector (500 ohm) Additional
Interface Link: 30 ft. Braided Cable, 1 Data Cable
Status: 2500°C Variable Speed
Control (V/I) / Power Supply: 9000Hz, 110/220VAC, Single Phase
Power Consumption - Motor: Active
Power Consumption - SW: 250 Watts
SW: 20 Watts

Antenna Characteristic

| Frequency | Gain (±2dB) | Beam width in Azimuth (degrees) | Antenna Noise Temperature @ 30° E | Switcher Envelope (Tx or Rx, Min/Max) |
|----------------|--------------------|--|-----------------------------------|---------------------------------------|
| 11.7-12.75 GHz | 37 dBi @ 11.95 GHz | 2.0 degrees @ 12.0 GHz | 1.8° < θ < 2.8° = 35.6K | 1.8° < θ < 2.8° = 29.25 Log 0 dB |
| VSWR | 1.30:1 | Linear, Cross-polar Standard, Copol optional | 2.8° < θ < 4.8° = 32.25 Log 0 dB | 4.8° < θ < 10.0° = 30.0 Log 0 dB |

Physical Data

Approximate Weight (w/o SW/CA/IB): 82 lbs
Max. Length with FL Cable Connected: 53 inches
Height: 42 inches
Stowed: 42 inches
Deployed: 42 inches
Clearance: 42 inches
Approximate Case Weight (w/ antenna) (including case): 115 lbs

Antenna Controller

One button operation automatic satellite acquisition with frequency GPS/Compass/Active Sensors and user configurable satellite selection
Parallel Power Supply/Display/Link
Weight: Power Supply (C/A Approved) (1kg/2kg) only
Dimensions: 4.5 H x 1.5 W x 1.5 D
Risk: None (VU)
Weight: 4.5 lbs
Dimensions (inches): 15W x 8.0D x 1.75H

Environment

MVS750: Wind: 120 mph
Survival - Snow: 60 mph at 60°F
Operational: 30 mph gusting to 45 mph
MVS750P - Wind: 30 mph gusting to 45 mph
Operational: 30°F to 125°F
Temperature: 30°F to 160°F
Operational Storage

Specifications are subject to change without notice



TracStar Systems, Inc. • 2400 N. Orange Blossom Trail • Orlando, FL 32804

407.650.9054 • FAX 407.650.9086

WWW.TRACSTAR.NET SALES@TRACSTAR.NET

750-5-04 © TracStar Systems, Inc. 2004 All Rights Reserved



MVS960 SERIES Mobile Broadband Satellite Communications


The MVS Series from TracStar allows non-skilled personnel to operate mobile Very Small Aperture Terminal (VSAT) satellite communications equipment enabling the user to access any broadband application over satellite.

The MVS Series antennas are typically owned and operated by:

- ▶ Corporations with remote or mobile office and monitoring applications
- ▶ Federal, state and local government agencies for law enforcement, emergency response and homeland security communications
- ▶ Military rapid deployment, SATCOM on the pause applications

With TracStar's MVS Series antennas, users enjoy the same reliable, secure, high-speed IP based data communications they are accustomed to in the office, while mobile. Users can get connected *Anywhere/Anytime* for applications such as:

- ▶ Secure, high-speed digital communications
- ▶ High-speed Internet access
- ▶ Voice and Fax communications
- ▶ Teleconferencing
- ▶ Wide area private network extension
- ▶ Video broadcasting



Convert Any Vehicle to a Mobile Wireless Broadband Hot-Spot



The MVS Series of auto-acquisition antennas feature:

- ▶ Automatic satellite acquisition with a single button push
 - ▶ Rapid deployment and operation on every Ku-band satellite, worldwide
 - ▶ Works with every satellite modem
 - ▶ TracStar Technology eliminates the need for -
 - Special test equipment for antenna alignment
 - Computers or peripheral equipment to operate the antenna
 - Phone calls to network operators or service providers
- Every antenna comes equipped with the following standard equipment:
- ▶ High precision and stiffness, low backlash drive system
 - ▶ Built-in GPS and compass
 - ▶ Built-in satellite receiver
 - ▶ Built-in level compensation
 - ▶ Automatic polarization alignment
 - ▶ Safe and easy installation, no calibrations required



MOBILE WIRELESS BROADBAND
HIGH SPEED DATA - INTERNET - VOIP - FAX - VIDEO



MVS960 & 960P

MVS960/960P Specifications



Mobile Satellite Link
 The MVS960 will convert your leased or owned truck body into a satellite link for use in a remote location. The system includes a truck body, a second computer, or other device needed to operate the system. Good communication is made using a GPS ring fit solderless.



Mobile Satellite Link
 Early compatible ring fit middle antennae, the MVS960 is ready to display anytime. The beam is so rigid to accommodate flat roof or arch roof vehicle. The antenna automatically compensates for displacement to 10 degrees.





Control Panel

TracStar's On-Touch Go and Star Technology maintains ease of deployment. The antenna does not need panel cover a portable unit or a TV set mounted panel by systems level configuration. Panel may be used in standard operation or performing custom configurations.



Portability/MVS960P

The MVS 960P solution provides a rugged portable container for a satellite and high bandwidth, display, router, refrigerator. Cold removal of the cover allows access to a ready-to-deploy antenna.



Reflector
 Size: 34x45
 Mount: 34x45
 Polarization: 34x45 Polarization over Azimuth
 Rotation of Reflector/Feed System: 360°/0° Azimuth

Tilt/az
 Azimuth: 400° or ±200° from Slow Position
 Elevation: 0.65° (-) slow position
 Polarization: 45° or ±90°

Trawl/Velocity
 Slow/Delaying: 10°/8 second
 Manual Jog: 5°/8 second
 Azimuth: 10°/8 second
 Elevation: 5°/8 second
 10° or 0.2°/8 second

Electrical Interface
 RF: 250 TX/RX Type F Connector
 Interface Link: 30 Ft. 28x RG6 Coax 1 Data Cable
 Modem: 24VDC Variable Speed/Serial Encoder
 Controller (U/I) / Power Supply: 5V/0.1Hz, 110/220VAC, Single Phase
 Power Consumption - Modem Active: 300 Watts
 Power Consumption - Modem Idle: 20 Watts

Antenna Characteristics

| | Receive | Transmit |
|--------------------------------|-----------------------|---------------|
| Frequency | 10.70-12.75GHz | 13.75-14.6GHz |
| Gain (±2dB) (Model) | 38.7 dBi @ 11.95GHz | 41.2 dBi |
| Beamwidth (1/2dB Az) (degrees) | 1.6 @ 1.2GHz | 1.5 @ 14.0GHz |
| Antenna Noise Temperature | 10° Elevation Azimuth | 1.5 dBi |
| Antenna Noise Temperature | 20° Elevation Azimuth | 39K |
| Antenna Noise Temperature | 30° Elevation Azimuth | 32K |

Antenna Cross-Polarization
 Stable Envelope (TX, Co-Pol, dB)
 1.8°-6.00°: 28.25 dBi @ 0
 20°-6.25°: 3.5
 26.25-6.48°: 26.25 dBi @ 0
 48°-6.80°: -10 (Typical)
 VSWR: 1.3 (Max)
 Isolation: 100dB (Min)
 Feed/Interference: WRT to Cover Range (100/120) WRT to Cover Range (100/120)

Physical Data

Approximate Weight (w/o LNB): 100 lbs
 Max Length w/ LNB Cables Connected: 88.3
 Height: 17.1" - 15.20" Option
 Stowed: 17.1" - 15.20" Option
 Deployed: 55.0
 Case Weight/Dimensions: 170 lbs / 43.0L x 28.5W x 20.5H
 Reflector Case: 126 lbs / 42.75L x 12.0W x 25.5H

Antenna Controller

One button operation automatic satellite acquisition with integrated GPS/Compass/Level Sensors and user configurable satellite selection.
 Provide Power Supply/Display Unit
 Weight: 4.5 lbs / Display Unit: 0.5 lbs
 Power Supply: 5W/10.25 DC 5V
 Display Unit: 5.5W/3.5V x 1.588H
 Ref. Mount (U/I) Weight: 4.5 lbs
 Dimensions: 18.0W x 8.0D x 1.75H

Environment

MVS960 - Wind Survival Stowed: 125 mph
 Operational: 60 mph @ 60° F
 MVS960P - Wind Survival Stowed: 125 mph
 Operational: 60 mph @ 60° F
 Temperature: 20° to 125° F
 Humidity: 20% to 125%
 Storage: 20° to 125° F

Specifications are subject to change without notice.

TracStar Systems, Inc. • 2400 N. Orange Blossom Trail • Orlando, FL 32804
 407.650.9054 • FAX 407.650.9086
www.tracstar.net sales@tracstar.net



MVS1200 SERIES Mobile Broadband Satellite Communications

The MVS Series from TracStar allows non-skilled personnel to operate mobile Very Small Aperture Terminal (VSAT) satellite communications equipment enabling the user to access any broadband application over satellite.

The MVS Series antennas are typically owned and operated by:

- ▶ Corporations with remote or mobile office and monitoring applications
- ▶ Federal, state and local government agencies for law enforcement, emergency response and home-land security communications
- ▶ Military rapid deployment, SATCOM on the pause applications

With TracStar's MVS Series antennas, users enjoy the same reliable, secure, high-speed IP based data communications they are accustomed to in the office, while mobile. Users can get connected *Anywhere/Anytime* for applications such as:

- ▶ Secure, high-speed digital communications
- ▶ High-speed Internet access
- ▶ Voice and Fax communications
- ▶ Teleconferencing
- ▶ Wide area private network extension
- ▶ Video broadcasting



The MVS Series of auto-acquisition antennas feature:

- ▶ Automatic satellite acquisition with a single button push
- ▶ Rapid deployment and operation on every Ku-band satellite, worldwide
- ▶ Works with every satellite modem
- ▶ TracStar Technology *eliminates* the need for -
 - ▷ Special test equipment for antenna alignment
 - ▷ Computers or peripheral equipment to operate the antenna
 - ▷ Phone calls to network operators or service providers

Every antenna comes equipped with the following standard equipment:

- ▶ High precision and stiffness, low backlash drive system
- ▶ Built-in GPS and compass
- ▶ Built-in satellite receiver
- ▶ Built-in level compensation
- ▶ Automatic polarization alignment
- ▶ Safe and easy installation, no calibrations required



Convert Any Vehicle to a Mobile Wireless Broadband Hot-Spot



MVS1200

MVS 1200 / 1200P Specifications

Mobile Satellite Link



The MVS1200 will connect from covered to unobstructed, located on in a low mount. The simple path of a beam will get the link in either mode. There are no external computers or other devices needed to operate the antenna. System connections are made by using a GPS single cable's probes.



Ease of Deployment
 Easily configurable in any mobile environment, the MVS1200 is easy to deploy anywhere. The base is designed to accommodate fit over rack mount vehicles. The antenna automatically compensates for steep surfaces up to 70 degrees.


OPTIONS



Control Panel
 Tracker's One Touch Go and Slow Recharge maintains ease of deployment. The main drive control panel comes in a portable handheld unit or a 1U rack mount panel. The controller is used for standard operation, or for configuring the antenna by web-site operation.



Portable MVS1200P
 The MVS1200P2 option provides a rugged 2-piece reflector with a portable container for a storable and highly durable rapid deployment requirement. Quick assembly of the reflector allows full access to a ready-to-deploy antenna in minutes.



*Load frame is used for mounting antenna to rooftops to distribute weight across a greater area and provide additional structural integrity to the mount mechanism.



Reflector

Size
 Omni Mount Geometry
 Polarization

1.2M Prime Focus Offset
 Elevation over Azimuth
 Radiation of Field

101

Travel

Azimuth
 Full Coverage
 Elevation
 Standard Configuration
 Polarization

±200° Roll-Off from Slow Position

0-67° of Reflector In-sight

±65°

Travel Velocity

Steering/Deploying
 Tracking
 Manual Jog

2°/Second
 5°/Second
 10° or 0.2°/Second

Electrical Interface

RF
 Interfacing Link
 Motors
 Controller (1U) / Power Supply
 Power Consumption – Motors Active
 Power Consumption – Idle

75Ω 1V / 1k Type F Connector (500Ω optional)
 30ft. 2se. RG8 Coax, 1 Control Cable
 28VDC Servo W. Quartz Encoder
 5000Hz 110V220VAC Single Phase
 250 Watts
 30 Watts

Antenna only.
 Does not include
 RF or base band
 equipment

Antenna Characteristics

Frequency
 Gain (±2dB)

Receive
 90.95 – 1275 GHz
 41.5 dBi
 1.901

Transmit
 1375 – 14.53GHz
 43.0 dBi

Antenna Noise Temperature

20° E
 30° E
 Within 108 contour
 Any Angle of Azis

Antenna Cross-Polarization

4%
 4%
 -30dB Max
 -25dB Max

Scalable Envelope Co-Pol (dB)

1.0° < θ < 20°
 20° < θ < 20.9°
 20.9° < θ < 48°
 48° < θ

VSWR

29.25 Log θ/63
 -3.5 dBi
 32.25 Log θ/63
 -10.0dB (Typical)
 1.3:1 Max

Physical Data

Approximate Weight (w/o BUOTUB)
 Max. Length with FUL Cable Connected
 Height
 Stowed (w/o loadframe)
 Deployed (w/o loadframe)
 Emergency Drive

50 lb (23)
 7ft
 17
 72.25
 Manual Hand crank of Az & El Axis

Antenna Controller

One button operation automatic satellite acquisition with integrated GPS/Compass/level sensors and user configurable satellite selection
 Portable/Power Supply/Display Unit
 Weight
 Dimensions
 Rack Mount (1U)
 Weight
 Dimensions (inches)

4.5 lbs / 5 lbs
 9"W x 10.25"D x 2.5"H
 5.5"W x 3.5"D x 1.58"H
 4.5 lbs
 19"W x 8.00" x 1.75"H

Environmental

Wind
 Survival - Stowed
 Survival - Operational
 Temperature
 Operational
 Storage

100 mph
 40 mph
 -20°F to 125°F
 -30°F to 140°F

Specifications are subject to change without notice

TrackStar Systems, Inc. • 2400 N. Orange Blossom Trail • Orlando, FL 32804
 407.650.9054 • FAX 407.650.9096
www.trackstar.net sales@trackstar.net
 1200-04 © TrackStar Systems, Inc. 2004 All Rights Reserved






Appendix B – Connection Directions

Modem and Voice Equipment Connection / Wiring Diagrams

NOTE: For VoIP follow EMS w/EdgeAccess connection information for the EdgeAccess Equipment




Gilat 360E Connection






EMS Technologies Connection






EMS with EdgeAccess Connection






iDirect Connection






Linkstar Connection





Vipersat Connection






MENU GRID



VSAT IDD Menu Grid



**- PROPRIETARY
INFORMATION - DO
NOT DUPLICATE**

